

Installation Guide: Fixing Posts In Ground

Using slimline metal posts



The GARDEN TRELLIS Co.
 Est. 1992 Crafted garden joinery

1. Use a string line to provide a guide for the position of the posts.
- Mark out & dig the holes for the slimline metal posts. We recommend a hole 200mm circumference by 600mm depth.
2. Insert post. Use spirit level to ensure it is level in both directions & correctly positioned against the string line. Posts need to be set at the correct width.
3. Fill the hole with post mix (use manufacturer's instructions). Adjust post into position and support until post mix sets.
4. Please check that tops of each post are at a uniform height, unless there is a change in heights required.
5. Repeat steps 2-4 as needed. Use spirit level to check each post is at correct height for panels.
6. Screw panels into posts:

PANELS BETWEEN POSTS
****Fixing strips required****

Screw fixing strips to the **back edge** of the posts from behind,

Screw panels into fixing strip from the front using 4.5mm x 50mm steel screws (minimum of 3 per side)

Ensure the top of each panel is level.

Optional:
 End strips of timber can be purchased to finish off the scheme

