


Installation Guide: Face Fixing for brick walls

1. Assess how level the wall is. You may require packers to level the posts.

2. Drill a hole to accept the plug. Use the appropriate drill bit for the fixing you are using.


Avoid fixing into the top course of bricks.



3. Fix the posts using your chosen fixings.

4. Fix the panel which will give the line & position of subsequent panels.

5. Repeat steps 2-4



6. Screw panels into posts:

Screw panels into posts using 4.5mm x 50mm stainless steel screws (minimum of two per side)

Trellis:

Through the frame into the side of the post

Ensure the top of each panel is level

Slatted:

Through the gap between slats (if possible), or directly through the horizontal slat.

Slatted panels fix onto the face of the posts.

Ensure the top of each panel is level.

Additional panels meet over the centre of the post, with the first and last sitting flush at the ends.

7. If installing top capping:

Trellis:

Align with the front edge of the post and screw down through the capping and into the top of the panel frame using 4.5mm/5mm x 100mm stainless steel screws (this can be plugged and filled if preferred).

Slatted:

Align with front slat of panel and screw down into top of posts and centre vertical (if possible) using 4.5mm/5mm x 100mm stainless steel screws (this can be plugged and filled if preferred).

